SANY KLEEN PLUS

DISINFECTANT SANITIZER

DÉSINFECTANT ASSAINISSANT

Sany Kleen Plus makes the ultimate cleaner, disinfectant and deodorizer. This formula reduces the hazards of crosscontamination between environmental surfaces and controls mould and mildew and the odours that they emit. Kills 99.99% of bacteria/fungi/viruses.

DESCRIPTION

USAGE



DIN 02511126

AVAILABLE IN: 4 L, 20 L

APPLICATIONS



:0DE:ENV502

Toilet, sinks, counters, garbage

bath area, exercise area,

cans, locker rooms,

hospitals



For hard surfaces and/or objects that may come into direct contact with children at the mouthing stage of development, a rinse with potable water is recommended.

1 L of water. Apply to surface with mop, cloth, sponge or trigger sprayer and allow

surface to remain wet for 10 minutes before wiping or let dry. Rewet surface if necessary. Pre-clean heavily soiled areas. Prepare a fresh solution for each use.

Areas of use: Vet Clinics, Dental Clinics, Medical clinics, Schools, Bathrooms and Exercise areas. Directions for use: For use on hard, non-porous surfaces including floors, walls, countertops,

appliances, tools, tables, handles. For disinfecting and sanitizing, dilute 16 mL of product to

Remove all animals/poultry and their feed from premises prior to disinfection. Remove all heavy soil, such as urine and fecal matter, from hard surfaces and objects prior to disinfection. Empty all feeding and watering appliances prior to disinfection. Following disinfection, do not house animals/poultry until areas have been ventilated. All surfaces and/or objects that will contact feed or drinking water should be rinsed with potable water before reuse.

Avoid contact with food. For surfaces or objects that may come in contact with food, rinse surface prior to use.

This product is not to be used as a sterilant/high-level disinfectant on any surface or instrument that: (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high-level disinfection.



Our specially formulated sanitizer contains carefully selected biodegradable ingredients and is free of harmful phosphates to protect our waterways from toxic algal blooms.



BIODEGRADABLE





SPECIFICATIONS

Physical form Liquid
Colour Yellow
Odour Citrus
pH (direct) 10.5
Flammability Not flammable

STORAGE







Store away from direct sunlight and heat



Store in original container with closed lid, away from incompatible materials such as strong acids.

SHELF LIFE: 1 year minimum from manufacture.

ACCESSORIES

ITEM: CODE: Microfibre cloths (blue) HSC-2512B

Trigger sprayer RAW-TS100

Enviroway spray bottle RAW-B95E

PACKAGING



This packaging is made from high density polyethylene (HDPE) one of the most commonly and easily recycled plastics!

Concentrated products save on packaging, energy, and emissions associated with transport. Instead of shipping mostly water, we are sending you a super concentrated product that you simply dilute with tap water. This allows us to pass the savings on to you!

AVAILABLE IN: 1L, 4L, 20L

PRECAUTIONS

Wash thoroughly after handling. For more information or Safety Data Sheets (SDS) please contact us or see our website.









